

DX-610/DX-626

6 CH DMX Dimmer Pack

【User Manual】



Lite Puter Enterprise Co., Ltd.
Website: www.liteputer.com.tw
E-mail: sales@liteputer.com.tw

INDEX

1. Safety Introduction	1
1-1 The Load Power	1
1-2 Working Environment	1
1-3 Suggested Dimming Fixtures	1
2. Introduction	2
2-1 Feature	2
2-2 Brief Device Introduction	2
2-3 Specification	2
2-4 Front Panel.....	3
2-5 Output Terminal Board / Sockets Panel	3
2-6 Wiring Diagram.....	4
3. Operation	5
3-1 DMX-512 Signal.....	5
3-2 Start Address Channel Setting.....	5
3-3 Patch Setting	6
3-4 Dimming/Switch Setting.....	6
3-5 Warm-Up Setting (0 – 6%).....	7
3-6 Manual Dimming.....	7
3-7 Display the Dimming Value of DMX Channel and Internal Temperature. 7	
3-8 DMX-512 Status & DMX-512 Address.....	7
3-9 Protocol Control	7
3-10 Memory Initialization.....	8
Limited Warranty	9

1. Safety Introduction

1-1 The Load Power

Please refer to the data we suggested to ensure the normal total working hours of DX-610/DX-626.

- If DX-610/DX-626 is installed in a rack, please make sure the rack has adequate ventilation. Otherwise the machine will become over-heat and result in the mal-function
- DX-610: the max. output of each channel is 10A: For testing (DO Not over 30 minutes)
- DX-626: the max. output of each channel is 20A: For testing (DO Not over 30 minutes)
- DX-610: the output of each channel is $\leq 8A$: For several hours usage (Theaters, Stages)
- DX-626: the output of each channel is $\leq 16A$: For several hours usage (Theaters, Stages)
- DX-610: the output of each channel is $\leq 8A$: Can work 24/7 without switching off (Hotels, Restaurants, Buildings)
- DX-626: the output of each channel is $\leq 12A$: Can work 24/7 without switching off (Hotels, Restaurants, Buildings)

1-2 Working Environment

- Temperature : $< 35^{\circ}C$
- If the machine is installed in a rack, then the temperature inside the rack must be under $45^{\circ}C$
- Humidity : 40% - 80%

1-3 Suggested Dimming Fixtures

Incandescent lamps, halogen lamps, low volt halogen lamps with ballast.

2. Introduction

2-1 Feature

- 6 dimming channels.
- Auto tracking of frequency and phase.
- Temperature control device: When the temperature is over 45°C , the fan will start automatically.
- Auto tracking of frequency: Enables stable dimming output in different frequencies.
- Testing function: Can do test without connecting to a console.
- Warm-up function to protect the loads. (Warm-up setting 0---6.0%)

2-2 Brief Device Introduction


- DX-610: 10A magnetic circuit breaker.
- DX-626: 25A magnetic circuit breaker.
- Thermal-controlled fan (37CFM X 1)
- The front panel can be dismantled easily for quick repair.



2-3 Specification

- Power Input: AC 100-240V, 45-63Hz, 3Ø4W, 1Ø2W
- Output: DX-610: Maximal output is 10A each channel
DX-626: Maximal output is 20A each channel
- DMX signal output/ input: DMX-512/ 1990
- DMX signal connector: XLR 5Pin, RJ11-6p4c phone jack
- Analog signal power input: DC 0-10V
- Analog input channel: 6 channels
PIN 1~6→ CH1~6, PIN 7→ NC
PIN 8→V+12V OUT, PIN 9→GND
- Analog signal connector: D-Type Plug 9 Pin (F)
- Dimension: 482(W) x 88(H) x 300(D)mm
- Installation: 19" 2U standard rack
- Weight: 8Kg
- Fuse: DX-610-PCB No.: MI23B4 F1 (Tube fuse 2.5A, 250V)
DX-626-PCB No.: MI23B4 F1 (Tube fuse 2.5A, 250V)


2-4 Front Panel



(1) Power on/ off switch	(5) Function Key
(2) DMX OUT/ IN (5 pin)	(6) Dimming VR of Channel 1- 6
(3) DMX IN (RJ11, phone jack)	(7) No fuse breaker (Channel 1-3)
(4) LED display/ function keys	(8) No fuse breaker (Channel 4-6)

2-5 Output Terminal Board / Sockets Panel

TERMINALTYPE



(9) DMX connector (RJ11, phone jack)
(10) DMX IN (XLR-3 pin)
(11) DMX OUT (XLR-3 pin)
(12) Output terminal board (External power no fuse breaker is necessary when mounting.)
(13) Power input terminal board. (DX-610: 20A Single phase; DX-626: 40A Single phase)

AMERICAN TYPE

Output sockets (DX-610: 10A each channel;

DX-626: 15A each channel, external power no fuse breaker is necessary when mounting.)







SCHUKO TYPE

Output sockets (DX-610: 10A each channel;


DX-626: 16A each channel, external power no fuse breaker is necessary when mounting.)



2-6 Wiring Diagram

<p>3 PHASE 4 WIRE</p> 	<p>THE BEST WIRING DIAGRAM</p> 
<p>1 PHASE 2 WIRE</p> 	

There are '3 PHASE 3 WIRE' and 'SINGLE PHASE 2 WIRE' as option.



3. Operation

3-1 DMX-512 Signal



This point is blinking while receiving DMX signal.

3-2 Start Address Channel Setting

STEP-1 holding **【DMX】** for 3 seconds until blinking A--- is displayed.



STEP-2 press **【▲】** or **【▼】** to find the start channel address. And then press **【DMX】** to confirm.



【▲】 : to go forward 1 address; up to 512th channel.



【▼】 : to draw back 1 address; start from 1st channel.

DX-626 is a 6 channels dimmer pack so while setting the DMX start channel address of this unit:

as d.001, the output is from Channel 1→ Channel 6.

as d.007, the output is from Channel 7→ Channel 12.

3-3 Patch Setting

STEP-1 holding **【DMX】** for 3 seconds until blinking A--- is displayed.



Set DMX start address as 3-2

STEP-2 Press **【FNC】** to shift channel, and press **【▲】** or **【▼】** to set the current channel address



DMX address of CH2 is 005

3-4 Dimming/Switch Setting

STEP-1 press **【DMX】** key into DMX status.

STEP-2 press and hold the **【FNC】** key for 3 sec.



Default setting: All channels are in dimming mode

STEP-3 press **【FNC】** key to select channel.

STEP-4 press **【▲】** or **【▼】** to select dimming mode or switch mode.



(Dimming)



(Switch)

3-5 Warm-Up Setting (0 – 6%)

STEP-1 press **【FNC】** key .



STEP-2 press **【FNC】** key to select the channel, EX :select channel 1

STEP-3 press **【▲】** , **【▼】** key to adjust.



Set warm-up level of
channel 1 as 6%

3-6 Manual Dimming

STEP-1 Push **【VR1-VR6】** to dim the output of each channel.

When there is another DMX input from a console, it will take the higher DMX value as the output.

3-7 Display the Dimming Value of DMX Channel and Internal Temperature.

Press **【L】** to display the dimming value of DMX channel.

Press **【T】** to display the internal temperature.

3-8 DMX-512 Status & DMX-512 Address


A. Press **【DMX】** to DMX status.

B.The LED will return to DMX status after 10 minutes idle.


3-9 Protocol Control

When the protocol control turn on, it only receive the DMX signal whose break width range from 88us to 230us.

STEP-1 Press **【FNC】** and LED displays as below.




STEP-2 Press **【▲】** and LED displays as below,



Protocol control is ON.

STEP-3 Press **【▼】** and LED displays as below,



Protocol control is OFF.

3-10 Memory Initialization

STEP-1: Press **【▲】** and **【▼】** at the same time and then turn on the device ,
LED shows:




STEP-2: Press **【FCN】** to cancel memory Initialization:



STEP-3: Press **【DMX】** to start memory Initialization:



Then LED display shows:



Limited Warranty

1. Lite-Puter is only responsible for the product itself.
2. Lite-Puter warrants to repair any manufacturing defects within one year of distribution date.
3. Lite-Puter does not offer on-site service. Should a defect appear in Lite-Puter' s product, please deliver the product to local distributors or Taiwan Headquarters.
4. This Limited Warranty does not cover:
 - a. Any fault caused by false usage or imprudence (collision, inadequate installation or adjustment, insufficient ventilation, or improper repairs)
 - b. Force majeure factors (flooding, earthquake, volcanic eruption, or other factors beyond Lite-Puter' s control).
 - c. Labor costs incurred in diagnosis of defects; installation, reinstallation, wiring, rewiring, repairing, adjustment, or reprogramming of a product; or any other consequential expenses.
 - d. Other Lite-Puter or non-Lite-Puter products or devices offered, packaged, or sold with the product.
5. Lite-Puter does not warrant that the product will operate without interruption or free of error.

Revision Record

Version	Record
A	First issued
H	Figures changed
I	Figures in 1-1,1-4 changed
J	Internal wiring diagram added
K	Typo edited
L	Change 2-3
M	Edit 2-2/2-7,delete 2-5,add 2-3
N	Memory Initialization 3-10
O	Page edited

Issued on: 2014/10

Lite-Puter

World Headquarters:

Lite-Puter Enterprise Co., Ltd.

Address: 11F, No. 189, Gangqian Rd., Neihu Dist., Taipei City 11494, Taiwan.

Tel: +886-2-27998099

Fax: +886-2-27993828

Website: www.liteputer.com.tw

E-mail: sales@liteputer.com.tw

Shanghai Factory:

Lite-Puter Technology (Shanghai) Co., Ltd.

Address: Building B5, No. 298, Lane 3509, Hongmei S. Road, Shanghai, China

Zip Code: 201108

Tel: +86-21-54408210

Fax: +86-21-54403376

Website: www.liteputer.com.tw

E-mail: sales_china@liteputer.com.tw